



## Option 24, Fairbanks Addressable

Value	Address	Scale
1	40 with 7 data bits odd parity	Scale 1
2	41 with 7 data bits odd parity	Scale 2
3	42 with 7 data bits odd parity	Scale 3
4	43 with 7 data bits odd parity	Scale 4/Total
5	40 with 7 data bits even parity	Scale 1
6	41 with 7 data bits even parity	Scale 2
7	42 with 7 data bits even parity	Scale 3
8	43 with 7 data bits even parity	Scale 4/Total
9	40 with 8 data bits no parity	Scale 1
10	41 with 8 data bits no parity	Scale 2
11	42 with 8 data bits no parity	Scale 3
12	43 with 8 data bits no parity	Scale 4/Total
13	46 with 7 data bits odd parity	Scale 2
14	52 with 7 data bits odd parity	Scale 3
15	58 with 7 data bits odd parity	Scale 4
16	64 with 7 data bits odd parity	Scale 5
17	70 with 7 data bits odd parity	Scale 6
18	76 with 7 data bits odd parity	Scale 7
19	82 with 7 data bits odd parity	Scale 8
20	99 with 7 data bits odd parity	Sum of all Scales

### Fairbanks 2550 Indicators use

40 Scale 1

46 Scale 2

52 Scale 3

58 Total

toll-free 800.814.4053  
fax 909.890.5991  
web [www.matko.com](http://www.matko.com)

Ship to:  
430 East Parkcenter Cir North  
San Bernardino, CA 92408

Bill to:  
PO Box 8891  
Redlands, CA 92375

**matko**  
ELECTRONIC DISPLAYS